

HOW-TO GUIDELINES – MASONRY CEMENT

INSTALLATION

Mixing: Machine mixing should be used whenever possible. First, add most of the water and half of the sand. Next, add the masonry cement and the rest of the sand. After one minute of continuous mixing, slowly add the rest of the water. Mixing should continue for at least three minutes; extending mixing up to five minutes improves mortar qualities.

No admixtures should be used without the written approval of the architect or engineer of record. Kosmortar Masonry Cements contain a water-repellent agent which is interground with the cement during finish grinding. No other additives are necessary, unless specified.

Retempering: To minimize retempering, mortar should not be mixed more than 15 minutes prior to use. Retempering will not adversely affect mortar quality if only evaporated water is replaced. Colored mortar should not be retempered.

Tooling of Joints: Tooling of mortar joints increases the density, durability and water tightness of the mortar surface. The moisture content of the mortar when tooled will affect the color; the drier the mortar, the darker its final color.